

12 June 2024

SPRING HINGE TENSION PROCEDURE

Tools Needed:

- 9/64 Allen key
- #1 Philips screwdriver

Parts Needed:

- COM-SPRING HINGE TENSION PIN
(pan head self-tapping screw)



Step 1: Insert Allen key into the bottom barrel of the hinge and rotate clockwise approximately 180 degrees to the third hole (looking where the tension screw will go).

Step 2: While holding the spring tension with the Allen key, insert the pan head screw and tighten with #1 Philips screwdriver.

Step 3: Release Allen key and test hinge for proper function.



UNTENSIONED

ROTATE CW TO TENSION

TENSIONED

If you have any further questions, do not hesitate to reach out to us.

info@canwayequipment.com

905-578-2929